

## Trusting - 7051 - Kit de freno

- Renault
- Trasero
- Bendix/Bosch
- Ø Tambor [mm]: 180
- Ancho Zapata [mm]: 40
- Ø Bombín [mm]: 22,00